

Pribor



NV rastavljači neizolirani

tip	I_N [A]	šifra	težina [g]	pakiranje [kom]
NV L 00	160	004941201	82	5/60
NV L 0	160	004941202	115	5/40
NV L 1	250	004941203	137	5/40
NV L 2	400	004941204	208	5/40
NV L 3	630	004941205	294	5/40
NV L 4	1250	004941208	740	5
NV L4a	1250	004941209	610	5

NEW!

NV rastavljači izolirani

tip	I_N [A]	šifra	težina [g]	pakiranje [kom]
NVLI 0	160	004941215	70	5/60
NVLI 0	160	004941216	120	5/40
NVLI 1	250	004941217	145	5/40
NVLI 2	400	004941218	215	5/40
NVLI 3	630	004941219	315	5/40

Drška

tip	I_N [A]	šifra	težina [g]	pakiranje [kom]
R 00-3	2-630	004941111	276	10
VR 00-3*	2-630	001691060	420	30


*Drška sa zaštitnim rukavom

Pribor

Signalna sklopka NVS 5

tip	šifra	težina [g]	pakiranje [kom]
NVS 5	004117001	11,5	10/340

Upotrebljava se za signalizaciju isklopa taljivih uložaka tipa NV/NH veličine NV/NH 00 C do NV/NH 3 (osim NV/NH 1 ultra sa noževima i za pričvršćivanje vijcima). NVS se aktivira preko indikatorske opruge.



Zaštitni elementi kontaktnih pera NVPP 00

tip	šifra	težina [g]	pakiranje [kom]
NVPP 00	004129301	33	24/168



Zaštitni elementi kontaktnih pera PK i PP

tip	šifra	težina [g]	pakiranje [kom]
PP 00	004129201	15	24/168
PK 1	004129001	13	42/504
PK 2	004129002	19	18/216
PK 3	004129003	19	21/315



Prozirni štitnik NVPP 00

tip	šifra	težina [g]	pakiranje [kom]
NVPP 00	004129310	16	24/168



Zaštitni rastalni uložak

tip	šifra	težina [g]	pakiranje [kom]
NVL00	004941206	30	10
NVL 1-3	004941207	78	10



Pregrade za osnovu

tip	šifra	težina [g]	pakiranje [kom]
NVPP 00	004941310	18	40/1000



Pregrade za osnovu

tip	šifra	težina [g]	pakiranje [kom]
PP 00, PK 00	004941301	50	20/100
PK 0	004941302	50	20/100
PK 1	004941303	50	20/100
PK 2	004941304	50	20/100
PK 3	004941305	50	20/100

